



VOGUE CHANGER

INSTRUCTION

CONTACT US

info@lovencare.com.au

PH: 1300 732 599

297 Canterbury Rd, Revesby, NSW 2212

loveⁿcare

www.lovencare.com.au



FIG 1



FIG 2

1. Attach the wheels to the changer ends as shown in FIG 1.

2. Attach the side rails to one changer end as shown in FIG 2.

Note: do not tighten the bolts at this step.



FIG 3



FIG 4



FIG 5

3. Put the boards into the gaps of the side rails as shown in FIG 3.

Note: do not tighten the bolts at this step.

4. Attach another changer end to attach the others.

Note: do not tighten the bolts at this step.

5. Tighten the bolts to finish the assembling.