



## SAFETY MESH BED RAIL

BP 54SD

BP 42SD

**STEP 1:** Make sure all parts are enclosed in the box.

- mesh bed rail
- 2 x mattress arms

**STEP 2:** Insert the tapered end of frame B into frame A.

**STEP 3:** Insert the tapered end of frame D into frame C.

**STEP 4:** Lay the mesh frame and the mattress arms on a flat surface. Depress the snap button on the mattress arm E and insert the tapered end into the bottom of the mesh frame A until the button pops into the predrilled hole on the side of the bed rail frame. Repeat with mattress arm F and frame B.

**TO USE THE BED RAIL:** Depress the snap Buttons fully into the frame then turn the Mattress arms 90 degrees and slide up into The mesh frame until the snap button pops into the hole. Slide the mattress arms between the mattress and box spring until the bed rail is snug against the mattress. There is added straps for a slattered bed.

**TO STORE THE BED RAIL:** Depress the snap buttons and fold the mattress arms to a flat position making sure to pop the snap buttons into place. Store the Bed Rail under the mattress.

**DEPRESS SNAP BUTTON FULLY:** Do not Force the mattress arms without depressing The snap button as this could cause permanent Damage.

**WARNING: THIS BED RAIL IS INTENDED FOR USE WITH CHILDREN 6 MONTHS TO 36 MONTHS OF AGE. DO NOT USE IN CRIBS OR ON BUNK BEDS.**

" Important, Retain this instruction for future reference."

